

# Site manual

Microresina

- **Microresina**
- **Microresina Floor**
- **Microresina Parquet**

**kerakoll**



## Contents

### **Microresina**

Microresina	04
Microresina Floor	18
Microresina Parquet	36
Legno+Color Nat	50

# Microresina

Coloured water-based micro-resin with a matt finish for the re-design of all types of furnishing accessories, ceramic and wood coverings and floors.

Microresina is an elastic ultra-thin film for the recolouring of doors, internal and external frames and heating fixtures. Furthermore, it decorates existing ceramic coverings and joints, transforming them into surfaces with a clean, contemporary look.

## Use

---

Microresina is ideal for:

- Wood, aluminium and PVC doors and window frames
- PVC and aluminium frames and plaques
- radiators, heated towel racks, lighting fixtures and metal furnishing accessories
- MDF, multilayer, or solid wood furniture
- previous ceramic coatings, glass mosaic, natural stone.

For internal and external use (on windows and window frames), in domestic and commercial environments.



# Preparation of substrates

## Preparation

### Warnings about substrates

- Temperature range for application: from +10 °C to +30 °C.
- Relative environmental humidity:  $\leq 75\%$ .

### Suitable substrates

- New wood.
- Painted, veneered or melamine wood.
- New metal.
- Painted metal.
- Plastic (hard pvc) and laminated furnishing accessories.
- Non-ferrous metals (aluminium).
- Ceramic, glass mosaic and natural stone previous coatings.

## Keragrip Eco Pulep


Organic preparation coat for treatment and cleaning of non-absorbent substrates.

→ Painted wood, painted iron, PVC, ceramic tiles



### Products

Pack - 1 l - 10 l




### Coverage

≈ 30 ml/m<sup>2</sup>



### Tools

cloth



### Time

Waiting time for overlaying:  
≈ 5-10 minutes

## Keradecor Sintcrom

Organic, mineral rust-preventive, anti-corrosive paint.

→ NEW METAL




### Products

Pack - 2.5 l - 0.5 l




### Coverage

≈ 150 - 200 ml/m<sup>2</sup>  
for 2 coats



### Tools

Brush and roller




### Time

Waiting time for overlaying:  
≈ 24 hours

## Preparation of substrates

### Microresina



#### **New wood**

- Apply one coat of **Microresina** diluted to 10-15% as a base.
- Sand the 1<sup>st</sup> base coat after it has fully dried until an even and smooth surface is achieved.



#### **PAINTED, VENEERED OR MELAMINE WOOD**

- Sand the surface with a pad (Scotch-Brite), remove any debonded part with sandpaper and then clean with a cloth soaked in **Keragrip Eco Pulep**.

Tip: Wallpaper may be used to grout any imperfection.





### **NEW METAL**

- Use a wire brush to eliminate rust or mill scale.
- Clean the surface and apply Keradecor Sintcrom rust-preventive paint.



### **PAINTED METAL**

- Sand the surface with a pad (Scotch-Brite) and then clean with a cloth soaked in **Keragrip Eco Pulep**.
- Tip: if any rust is present in areas showing debonded paint, remove carefully and apply Keradecor Sintcrom.

## Preparation of substrates

Microresina



### **PLASTIC (HARD PVC) AND LAMINATED FURNISHING ACCESSORIES**

→ Sand the surface with a pad (Scotch-Brite) and clean with a cloth soaked in **Keragrip Eco Pulep**.



### **Aluminium**

→ Sand the surface with a pad (Scotch-Brite) and clean with a cloth soaked in **Keragrip Eco Pulep**.



**Ceramic, glass mosaic and natural stone previous coatings**

→ Check the moisture in the joints (< 2% CM) before applying.

→ Prepare the surface by passing a cloth soaked in **Keragrip Eco Pulep** over it.

→ Before application, check that the temperature of the ceramic surface is warmer than +10 °C.

Tip: check the uniformity of the grouts, if necessary proceed with localised re-grouting. Check that no silicone or acetic sealants have been used; if that is the case, remove them with suitable products in order to eliminate any oily film.

# Application

## Preparation

- Before use, stir part A, add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1 and mix well until completely blended.
- Dilute using clean water up to 10% and mix again.
- Use the prepared material within 1.5 hours from mixing.

## Microresina

Coloured water-based micro-resin with a matt finish for the re-design of all types of furnishing accessories, ceramic and wood coverings and floors.



### Products

Pack – (1+0,2) 1,2 kg e (2,5+0,5) 3 kg



### Coverage


≈ 300 ml/m<sup>2</sup> for 2-3 coats

Dilution – max 10%



### Tools

Brush, roller, spray gun



### Time

Waiting time between 1<sup>st</sup> and 2<sup>nd</sup> coat: ≈ 6-12 hours (on ceramic tiles)

Waiting time between subsequent coats: ≈ 2-12 hours

## Application

### Microresina



→ Add part B to part A in the ratio part A : part B = 5 : 1 and mix well until completely blended.

→ Use the prepared material within 1.5 hours from mixing.



→ **Microresina** must be applied with a roller over the whole surface in **2-3 coats, diluted to a maximum of 10%.**

→ On non-absorbent surfaces apply the first coat pure.

→ Leave at least 6 hours between the first and second coats.



- Waiting time between subsequent coats  $\approx$  2-12 hours.
- If more than 12 hours elapses between one coat and the next, sand lightly with a **Softpad** abrasive before applying the subsequent coat.




- After application, the surfaces must be protected against dust, water and humidity until the film has dried completely.

## Application

### Microresina



→ On irregular surfaces, **Microresina** may be applied by brush in two, three or more coats until the required coverage is achieved (according to the colour used).



→ **Microresina** can be applied with a short-bristle roller, such as **Roller Plus**, or a sponge roller.

Tip: avoid air currents in the first half hour after application. Afterwards, a fan may be used in order to speed up drying times.





- **Microresina** can be applied by spraying.
- Dilute the product using water to a maximum of 30%, according to the system and the vertical/horizontal type of application.



Tip: be careful not to overload the surface in order to avoid drips or droplets.

# MicroresinaFloor

Water based coloured ultra-thin film. Ideal to re-design already existing ceramic, cement and resin floors.

Microresina Floor renews floors with elegance and simplicity, enhancing patterns, textures and irregularities to refresh your rooms and give them a clean, contemporary look.



## Use


---

Microresina Floor is ideal for:

- existing ceramic tile floors
- cement floors (concrete).

For internal use, in domestic and commercial environments with medium foot traffic.

Suitable for heated substrates and showers.



① Layer → Priming, according to the substrate

**Keragrip Eco Pulep**

② Layer → Coloured base

**Microresina Zero**

③ Layer → Coloured finish

**Microresina**

④ Layer → Transparent protective

**Microresina Xtreme**

# ① Layer → Priming

## Preparation

### Warnings about substrates

- The substrates must be permanently dry and free from rising damp.
- Maximum residual moisture on cement based and ceramic substrates: < 2%.
- Temperature range for application from +10 °C to +30 °C.
- Relative environmental humidity: ≤ 75%.

### Suitable substrates

- existing wall and floor coverings in single and double-fired ceramics, porcelain tiles, glass mosaic, cotto, natural stone treated with Keragrip Eco Pulep.
- cement floors (concrete).

## Keragrip Eco Pulep

Eco-friendly, organic preparation coat for treatment and cleaning of non-absorbent substrates.



### Products

Pack – 1 l - 10 l




### Coverage

≈ 30 ml/m<sup>2</sup>



### Tools

cloth



### Time

Waiting time for overlaying: ≈ 5-10 minutes for the subsequent application of **Microresina Zero**

## ① Layer → Priming

Keragrip Eco Pulep



### **On existing ceramic coverings, glass mosaic and natural stone**

→ Prepare the substrate made of ceramic with **Keragrip Eco Pulep**.

Tip: do not pour the adhesion promoter directly onto the floor in order to avoid damping the joints too much.

### **Checking the joints and possible grouting**

→ If the floor joints are broken or discontinuous, remove the damaged parts and vacuum the residues.

→ If necessary, proceed with re-grouting using a cement-based grout from the Fugabella range (it is advisable to choose the same finish as the existing joints) or an organic grout from the Fugalite range (fine finish).



**On cement or concrete**

- After suitable preparation and careful cleaning, apply EP21 diluted up to 30% with **Keragrip Eco Pulep**.
- Wait for 6 hours and apply a 2<sup>nd</sup> coat of EP21 diluted up to 10% with **Keragrip Eco Pulep**.
- Evenly spread the primer over the surface and avoid creating any build-up.

# ② Layer → Coloured base

## Preparation

- Before use, stir part A, add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1 and mix well until completely blended.
- Dilute using clean water up to 10% and mix again.



## Microresina Zero

Coloured micro-resin base coat for the re-design of existing floors with medium foot traffic.



### Products

**Pack** – (1,5+0,3) 1,8 kg e (5+1) 6 kg



### Coverage


≈ 200 g/m<sup>2</sup> in one coat

Dilution – max 10%



### Tools

Roller



### Time

Waiting time between subsequent coats: ≈ 6 hours (+30 °C) / 16 hours (+10 °C)

## ② Layer → Coloured base

Microresina Zero



→ Stir part A before use. Add part B in the ratio part A : part B = 5 : 1 and mix until completely blended.

→ Dilute the product up to 10% by weight using water and mix again.



→ Shape the corners with a brush or a small roller as you gradually proceed, so that the product can always be overlaid wet-on-wet.



→ On smooth substrates, apply **Microresina Zero** with a short-bristle roller.

→ In case of particularly irregular substrates or large joints, use 8-10 mm long-bristle rollers.



Tip: carefully and evenly apply the product in the joints as well. In joint areas, blend together by lifting up the roller, in order not to leave excess amounts of material.

# ③ Layer → Coloured finish

## Preparation

- Before use, stir part A, add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1 and mix well until completely blended.
- Dilute using clean water up to 10% and mix again.
- Use the prepared material within 1.5 hours from mixing.

## Microresina

Coloured water-based micro-resin with a matt finish for the re-design of all types of furnishing accessories, ceramic and wood coverings and floors.



### Products

Pack – (1+0,2) 1,2 kg e (2,5+0,5) 3 kg



### Coverage


≈ 100 g/m<sup>2</sup> in one coat

Dilution – max 10%



### Tools

Roller



### Time

Waiting time between subsequent coats: ≈ 2-12 hours

### ③ Layer → Coloured finish

Microresina



→ The **Microresina Zero** supporting layer must be carefully prepared: sand with a sander or floor buffer with **Carboplus Sic 220** abrasive pad to even the surface; clean thoroughly with a vacuum in order to remove all sanding residues.



→ **Microresina**: add part B to part A in the ratio part A : part B = 5 : 1 and mix well until completely blended.

→ Dilute the product up to 5-10% using water and mix again.



→ Shape with a small roller or brush as you gradually proceed, so that the product can always be overlaid wet-on-wet.

→ Apply in a criss-cross manner, evening out the product.



Tip: in overlapping areas, blend together by lifting up the roller, in order not to leave excess amounts of material. When applying in several connected rooms, leave gaps at the thresholds connecting the rooms by using the joints as breaks.

# ④ Layer → Transparent protective

## Preparation

- Shake part A before use and pour it into a clean tray.
- Add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1.
- Mix well, then dilute 10% using clean water and mix again.



## Microresina Xtreme

Transparent, water based micro-resin for the protection of Microresina Floor.



### Products

Pack – (1+0,2) 1,2 l e (2,5+0,5) 3 l



### Coverage


≈ 120 ml/m<sup>2</sup> for two coats

Dilution – max 5-10%



### Tools

Roller



### Time

Waiting time between subsequent coats: ≥ 2-3 hours

If more than 12 hours elapse, lightly sand with **Softpad**.

#### ④ Layer → Transparent protective

Microresina Xtreme



- Shake part A before use and pour it into a clean tray.
- Add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1. Mix well, then dilute 10% using clean water and mix again.



- Apply 2 coats of **Microresina Xtreme** with **Roller Plus** or a flat brush respecting the coverage of  $\approx 60 \text{ ml/m}^2$  per coat.
- Waiting time for the overlaying of successive coats of **Microresina Xtreme**:  $\approx 2\text{-}3$  hours.



→ If the second coat is applied within 12 hours it is not necessary to sand the surface.

→ If a period of over 12 hours has passed, sand with **Softpad**.

Tip: ready for use in domestic environments ≈ 2-4 days (foot traffic), ventilate all environments, do not cover, do not wash and do not walk on for at least 48 hours.

# MicroresinaParquet

Water-based, coloured micro-film, ideal to decorate and protect Legno+Color floors and to re-design parquet floors.

Microresina Parquet allows old hardwood floors to be renovated with a contemporary style, guaranteeing new colouring of the wood directly on site.



## Use

---

Microresina Parquet is ideal for:


- decoration and protection of **Legno Small, Legno Medium, Legno**

**Large** floors

- re-design of existing oak wood floors

- re-design of existing floors made of any wood other than oak.

For internal use, in domestic and commercial environments with high levels of foot traffic.



① Layer → Coloured finish

**Microresina**

② Layer → Transparent protective

**Microresina Xtreme**

# Preparation of substrates

## Preparation

### Warnings about substrates

- The hardwood floor must be bonded, stable and its moisture must be between 9 and 11%.
- Temperature range for application: from +10 °C to +30 °C.
- Relative environmental humidity:  $\leq 75\%$ .

### Suitable substrates

- Legno Large, Legno Medium, Legno Small floors.
- Floors made of oak.
- Wood floors made of any wood other than oak treated with Primer Antitannino.

## Softpad

Synthetic pad abrasive system with incorporated abrasive grain designed to give extra-fine, continuous and localised sanding even on irregular substrates.


→ **Legno Large, Legno Medium, Legno Small** floors / Oak floors

→ Wood floors made of any wood other than oak treated with **Primer Antitannino**



### Products

Pack – 10 pcs.



### Coverage

≈ 25 m<sup>2</sup> for side

## Primer Antitannino

Transparent base coat varnish for anti-tannin treatment of wooden floors before applying Microresina Parquet.

→ Wood floors made of any wood other than oak



### Products

Pack – 2.5 l




### Coverage

≈ 300 ml/m<sup>2</sup>



### Tools

Roller



### Time

Waiting time between subsequent coats ≈ 2-4 hours

Waiting time before overlaying ≈ 36 hours

## Preparation of substrates

### Microresina Parquet



#### **LEGNO LARGE, LEGNO MEDIUM, LEGNO SMALL**

→ Clean the hardwood floor from any hardened adhesive residues, taking care to eliminate any trace or stain with 60-grain sandpaper along both the vein and the texture. Sand with **Softpad** and vacuum with care.



#### **Floors made of oak**

→ Sand the hardwood floor, taking care to eliminate any trace of previous treatments. In order to enhance the grain of the wood and obtain a more material effect, wire brush the surface using specific equipment. Sand with **Softpad**, vacuum with care.





### **WOOD FLOORS MADE OF ANY WOOD OTHER THAN OAK**

- Polish and sand the hardwood floor, taking care to eliminate any trace of previous treatments. On woods that allow it, in order to enhance the grain and obtain a more material effect, wire brush the surface using specific equipment.
- To avoid the rising of tannin and other dyes, apply **Primer Antitannino** respecting the coverage of 300 ml/m<sup>2</sup> following the instructions of the technical data sheet.
- Sand with **Softpad**, vacuum with care.
- Waiting time between subsequent coats 2 - 4 hours.
- Waiting time for overlaying after the 3<sup>rd</sup> coat, 36 hours.

# ① Layer → Coloured finish

## Preparation

- Before use, stir part A, add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1 and mix well until completely blended.
- Dilute using clean water up to 10% and mix again.
- Use the prepared material within 1.5 hours from mixing.

## Microresina

Coloured water-based micro-resin with varnished matt finish to decorate Legno+Color floors and to re-design hardwood floors.



### Products

Pack - (1+0,2) 1,2 kg e (2,5+0,5) 3 kg



### Coverage


$\approx 220 \text{ g/m}^2$  for two coats

Dilution - max 10%



### Tools

Roller




### Time

Waiting time between subsequent coats:  $\approx 3-4$  hours

## ① Layer → Coloured finish

Microresina




→ Evenly apply the 1<sup>st</sup> coat of **Microresina** with **Roller Plus** respecting the coverage of  $\approx 110 \text{ g/m}^2$ .



Tip: apply first the product in one direction and then in the other, in order to obtain a complete and even coverage of both the texture and the chamfer.



→ After  $\approx$  3-4 hours, sand with **Softpad**, vacuum with care.



→ Evenly apply the 2<sup>nd</sup> coat of **Microresina** with **Roller Plus** respecting the coverage of  $\approx$  110 g/m<sup>2</sup>.

Tip: leave overlaps along the vein, avoid large overlaps or overlapping over long periods. If necessary, create distinct gaps along the vein or over doors and doorways.

# ② Layer → Transparent protective

## Preparation

- Shake part A before use and pour it into a clean tray.
- Add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1.
- Mix well, then dilute 10% using clean water and mix again.

## Microresina Xtreme

Transparent water based micro-resin with matt finish for the protection of Legno+Color floors and the re-design of hardwood floors.



### Products

Pack – (1+0,2) 1,2 l e (2,5+0,5) 3 l



### Coverage

≈ 80 ml/m<sup>2</sup> in one coat


≈ 160 ml/m<sup>2</sup> for two coats (for heavy foot traffic)

Dilution – max 10%



### Tools

Roller




### Time

Waiting time between subsequent coats: ≈ 2-3 hours

If more than 12 hours elapse, lightly sand with **Softpad**.

## ② Layer → Transparent protective


Microresina Xtreme



→ Evenly apply **Microresina Xtreme** with **Roller Plus** respecting the coverage of  $\approx 80 \text{ ml/m}^2$ .

Tip: leave overlaps along the vein, avoid large overlaps or overlapping over long periods. If necessary, create distinct gaps along the vein or over doors and doorways, using adhesive paper tape if need be.





### **AREAS SUBJECT TO HEAVY FOOT TRAFFIC**

→ After approximately 2-3 hours and in any case within 12 hours, evenly apply a further coat of **Microresina Xtreme** with **Roller Plus**, respecting the coverage of  $\approx 80 \text{ ml/m}^2$ .

→ If a period of over 12 hours has passed, sand with **Softpad**.

Tip: ready for use in domestic environments after  $\approx 2-4$  days (foot traffic), in commercial environments after  $\approx 7-10$  days, ready for washing/contact with water after  $\approx 48$  hours.

# Legno+Color Nat

Natural wood-effect finishing cycle for Legno+Color floors and the re-design of existing oak hardwood floors.




## Use

---

Legno+Color Nat is ideal for:

- decoration and protection of **Legno Small, Legno Medium, Legno Large** floors
- re-design of existing oak wood floors

For internal use, in domestic and commercial environments with high levels of foot traffic.



① Layer → Smoothing base

**Legno Nat Base**

② Layer → Transparent protective

**Microresina Xtreme**

# Preparation of substrates

## Preparation

### Warnings about substrates

- Temperature range for application: from +10 °C to +30 °C.
- Relative environmental humidity:  $\leq 75\%$ .

### Suitable substrates

- Legno Large, Legno Medium, Legno Small oak floors.
- Oak wood floors, brushed finish.
- For internal use, in domestic and commercial environments with medium foot traffic.
- Suitable for heated substrates.

## Softpad

Synthetic pad abrasive system with incorporated abrasive grain designed to give extra-fine, continuous and localised sanding even on irregular substrates.

→ **Legno Large, Legno Medium, Legno Small** floors / Oak floors



**Products**

Pack – 10 pcs.



**Coverage**

≈ 25 m<sup>2</sup> for side

# ① Layer → Smoothing base

## Preparation

### The product is ready-to-use

- Carefully shake before use.
- Poor the product into a clean container of a suitable size.
- During application remix the product in the container.

## Legno Nat Base

Natural-effect, single component, water-based preparation coat.  
To be used for base preparation in the Legno+Color Nat cycle.



### Products

Pack – 2.2 l



### Coverage


≈ 100 ml/m<sup>2</sup> for **Legno Large, Legno Medium, Legno Small**

≈ 100-150 ml/m<sup>2</sup> for traditional oak wood floors



### Tools

Roller



### Time

Waiting time for overlaying with **Microresina Xtreme**: ≈ 4 hours after sanding down

## ① Layer → Smoothing base

Legno Nat Base



### **LEGNO LARGE, LEGNO MEDIUM, LEGNO SMALL**

→ Clean the hardwood floor from any hardened adhesive residues, taking care to eliminate any trace or stain with 60-grain sandpaper along both the vein and the texture. Sand with **Softpad** and vacuum with care.



### **Floors made of oak**

→ Sand the hardwood floor, taking care to eliminate any trace of previous treatments. In order to enhance the grain of the wood and obtain a more material effect, wire brush the surface using specific equipment. Sand with **Softpad**, vacuum with care.





→ Evenly apply **Legno Nat Base** with **Roller Plus** respecting the coverage of  $\approx 100 \text{ ml/m}^2$ .

Tip: apply first the product in one direction and then in the other; evenly and gradually apply the product as it is absorbed.



→ After  $\approx 4$  hours, evenly and lightly sand **Legno Nat Base** with **Softpad**; do not break through the applied coat.

→ Carefully vacuum to remove all sanding dust.

Tip: be careful not to leave any marks on the sanded and vacuumed floor, remove any stain/footprint with **Softpad**.

# ② Layer → Transparent protective

## Preparation

- Shake part A before use and pour it into a clean tray.
- Add the hardening compound whilst stirring in the ratio part A : part B = 5 : 1.
- Mix well, then dilute 10% using clean water and mix again.

## Microresina Xtreme

Water-based transparent micro-resin with matt finish for the protection of Legno+Color Nat floors.



### Products

Pack – (1+0,2) 1,2 l e (2,5+0,5) 3 l



### Coverage


≈ 240 ml/m<sup>2</sup> in three coats

Dilution – max 5-10%



### Tools

Roller



### Time

Waiting time between subsequent coats: ≈ 2-3 hours

If more than 12 hours elapse, lightly sand with **Softpad**.

## ② Layer → Transparent protective

Microresina Xtreme



→ Evenly apply three coats of **Microresina Xtreme** with **Roller Plus** respecting the coverage of  $\approx 80 \text{ ml/m}^2$ .

Tip: apply first the product in one direction and then in the other, in order to obtain a complete and even coverage of both the texture and the chamfer.

Leave overlaps along the vein, avoiding large overlaps or overlapping over long periods. If necessary, create distinct gaps along the vein or over doors and doorways, using adhesive paper tape if need be.



→ **Waiting time before overlaying between coats, minimum 2-3 hours, maximum 12 hours.**

→ **If the second or third coat are applied within 12 hours it is not necessary to sand the surface.**

→ **If a period of over 12 hours has passed, sand with **Softpad**.**

Tip: ready for use in domestic environments after ≈ 2-4 days (foot traffic), in commercial environments after ≈ 7-10 days, ready for washing/contact with water after ≈ 48 hours.



# Surfaces and Uses

## Surfaces

---

### paints

Absolute  
Decor

---

### Resin-based Coating materials

**Decorative coverings**  
Wallcrete Living  
Wallpaper Living  
Patina Living  
Stripe Living

### Technical coverings\*

Wallcrete  
Wallpaper  
Patina

---

### Microresina

Microresina  
Microresina Floor  
Microresina Parquet

---

### Cementoresina

Cementoresina  
Cementoresina Wall

---

### Legno+Color

Legno+Color S, M, L

---

### Finishes for external application

Outdoor Paint  
Outdoor Plaster

---

### Skirting board

Invisibile

---



## Use

---

### Walls and ceilings

Absolute  
Decor

---

### Decorative walls

Wallcrete Living  
Wallpaper Living  
Patina Living  
Stripe Living

---

### Technical walls\*

Wallcrete  
Wallpaper  
Patina  
Cementoresina Wall

---

### Floors

Cementoresina  
Legno+Color S, M, L  
Microresina Floor  
Microresina Parquet

---

### Re-color\*\*

Microresina

---

### External facades

Outdoor Paint  
Outdoor Plaster

\* Walls of bathrooms and kitchens.

\*\* Doors, internal and external fixtures, joinery and ceramic coverings.

**Kerakoll Spa**  
via dell'Artigianato 9  
41049 Sassuolo (MO) Italy  
T +39 0536 816 511  
info@kerakoll.com

**Kerakoll Brera Studio**  
via Solferino 16  
20121 Milano (MI) Italy  
T +39 02 620 867 81

N.B.

This Site manual has been drafted on the basis of the best technical and practical knowledge of Kerakoll S.p.A.

It is, however, a set of guides and information of a general nature that do not consider the real situations of individual structures; therefore, the coverage information is to be considered merely indicative.

Kerakoll does not intervene directly in the building site conditions, the specific design of the project, and the execution of the work; the information and guidelines mentioned here do not commit Kerakoll in any way.

The designer in charge is responsible for the entire structural design in accordance with Italian Ministerial Decree 17/01/2018 and its amendments or additions.

All rights reserved. © Kerakoll. All rights to the content of this publication are reserved in accordance with applicable law.

The duplication, publication, and distribution, in full or in part, of all material contained herein, are expressly forbidden without written authorization. Additions and/or amendments to this information may be made over time by KERAKOLL Spa; for the latest version, see [www.kerakoll.com](http://www.kerakoll.com).

KERAKOLL Spa shall therefore be liable for the validity, accuracy and updating of information provided only when taken directly from its institutional website. For information on the product safety data, refer to the corresponding sheets provided in accordance with the law along with the health labelling on the packaging. Finally, it is advisable to perform a preliminary test of each product to verify its suitability for your purposes.



**kerakoll**



[kerakoll.com](http://kerakoll.com)